

# Kaymar

## Fitting Instructions



Vehicle Rodeo RA  
Year  
Type UTE  
Part Rear Bar

### Applicable to Part Numbers

K2205, KITROD-L-JCS

Date published December 6, 2016

## IMPORTANT - BEFORE COMMENCING INSTALLATION

Please verify the part number corresponds with the list above.

Read through these instructions and check items in the supplied fitting kit matches the attached list.

Every effort is made to ensure instructions are as accurate as possible at the time of publishing however work should not be commenced until the document has been thoroughly read, measurements checked and all components in the package verified as complete. Kaymar has used reasonable care in preparing the information included in these documents, but makes no representations or warranties as to the completeness or accuracy of the information. Information is supplied upon the condition that the persons receiving the information will make their own determination as to its suitability for their purposes prior to use. Kaymar assumes no liability whatsoever for any damages incurred by you resulting from errors in or omissions from the information included herein. Kaymar reserves the right to make changes without further notice to any products to improve reliability, function or design.

## RA RODEO

1. Remove original bumper bar assembly, number plate and towbar (if fitted). For easement of fitting also remove spare wheel from underneath of vehicle.

**\*\*\*Please check tub is square on the chassis and re-align if necessary before fitting Kaymar bar\*\*\***

2. Angle the rear bar so as the front of the long arms go up and fit to the outside of the chassis first. Push forward and upward until the two flat plates hit the bottom of the chassis and the two holes in each side line up with the holes in the bottom of the chassis rails.
3. Hold rear bar in place using the 4 x M10 bolts (with flat washers and spring washers), place them in the corresponding holes on the underside of chassis.  
Note: These have captive nuts situated in chassis. **DO NOT TIGHTEN**
4. Using the M12 x 35 x 1.25 bolts (with flat washers and spring washers) insert into chassis sides where corresponding captive nuts are situated. Do not tighten.

# Kaymar

## Fitting Instructions

5. Fit M12 bolts on wire through chassis (from inside to outside), at further most corresponding holes with M12 nut, spring and flat washer holding it in position.  
With all bolts in rear bar, tighten 4 x M10 bolts first, followed by all of the M12 bolts.
6. Fit the chequer plate with 6mm coach bolts, washers and nuts.
7. Using loom wire supplied, splice into original loom located underneath the body at the rear of the tailgate, wire auxiliary lights and trailer plug wire as per standard colour coding.

Refer to Wheel Carrier & Jerry Can Holder instructions if fitting attachments.

### BK2205 RA RODEO REAR BAR

QUANTITY	DESCRIPTION
6	BOLT M12 X 50 X 1.25 FINE THREAD
4	BOLT M10 X 30 X 1.25 FINE THREAD
2	BOLT ON WIRE M12 X 35 X 1.75 300 MM WIRE
2	NUT M12 X 1.75
10	WASHER FLAT M12 X 30 HD
8	WASHER SPRING M12
4	WASHER FLAT M10 X 30 HD
4	WASHER SPRING M10
2	WIRE TRAILER 7 CORE 400 MM LENGTH
8	WIRE CONNECTOR FEMALE
10	WIRE CONNECTOR SCOTCH BLUE

