

Kaymar

Fitting Instructions



Vehicle LandCruiser 200
Year
Type
Part Wheel Carrier
Removal

Applicable to Part Numbers

K20023L, K20023R, K20026L, K20026R, K20020L, K20020R,
K20025L, K20025R, K20022L, K20022R,

Date published March 9, 2017

IMPORTANT - BEFORE COMMENCING INSTALLATION

Please verify the part number corresponds with the list above.

Read through these instructions and check items in the supplied fitting kit matches the attached list.

Every effort is made to ensure instructions are as accurate as possible at the time of publishing however work should not be commenced until the document has been thoroughly read, measurements checked and all components in the package verified as complete. Kaymar has used reasonable care in preparing the information included in these documents, but makes no representations or warranties as to the completeness or accuracy of the information. Information is supplied upon the condition that the persons receiving the information will make their own determination as to its suitability for their purposes prior to use. Kaymar assumes no liability whatsoever for any damages incurred by you resulting from errors in or omissions from the information included herein. Kaymar reserves the right to make changes without further notice to any products to improve reliability, function or design.

REMOVAL OF TOYOTA 200 SERIES CARRIER INSTRUCTIONS

1. Remove lock plate and wheel from carrier.
2. Place masking tape around painted area of bumper, where carrier is to be removed.
3. From under vehicle remove the four bolts holding the silver pivot bracket to the main corner bracket.



Kaymar

Fitting Instructions



(Note: with carrier in the open position, the gas strut can be left on)

4. Lower carrier arm and bring silver pivot bracket out through cut-out in bumper.



5. If fitting Kaymar reflector bracket, see separate fitting instructions.

