Eitting Instructions

Suitable fo	>r
All Rear	Bars
Year	
Туре	
Part	Rear Bar

Applicable to Part Numbers All rear bar pivots

Date published February 5, 2020

IMPORTANT - BEFORE COMMENCING INSTALLATION

Please verify the part number corresponds with the list above. Read through these instructions and check items in the supplied fitting kit matches the attached list.

Every effort is made to ensure instructions are as accurate as possible at the time of publishing however work should not be commenced until the document has been thoroughly read, measurements checked and all components in the package verified as complete. Kaymar has used reasonable care in preparing the information included in these documents, but makes no representations or warranties as to the completeness or accuracy of the information. Information is supplied upon the condition that the persons receiving the information will make their own determination as to its suitability for their purposes prior to use. Kaymar assumes no liability whatsoever for any damages incurred by you resulting from errors in or omissions from the information included herein. Kaymar reserves the right to make changes without further notice to any products to improve reliability, function or design.



How to measure carrier pivot diameter for bearing size

Please note:

If the diameter is 39mm the K6032 bearing kit is required

If the diameter is 45mm the K6031 bearing kit is required



90 Beresford Road, Lilydale, Vic, 3140, Australia www.kaymar.com.au sales@kaymar.com.au P: +61 3 9739 4110 F: +61 3 9739 4111

Date published February 5, 2020