## Eaymal Fitting Instructions

## Carrier Locking Handle Measurement Requirement

The distance between the red lines must be exactly as specified in the fitting instructions.

It is imperative the distance is 35mm for the catch to operate correctly.

